

Column Specifications

Tuscan Cap and Base Dimensions

BOT. DIA	TOP DIA	Square Plinth		Round Base		Total Base	Round Cap			Square Abacus		Total Cap
A	B	C	D	E	H	E & H	M	J	L	N	O	L & N
12	10	16 1/8	2 3/4	2 3/8	7/8	3 1/4	13/16	2 1/8	1 3/8	2	14 3/8	3 3/8
14	12	18 3/4	3 3/8	3	1	4	7/8	2 5/8	1 5/8	2 3/8	17 1/8	4
16	13 1/2	21 1/2	3 7/8	3 3/8	1 1/8	4 1/2	1	3	1 7/8	2 3/4	19 1/4	4 5/8
18	15	24 1/4	4 1/4	3 7/8	1 1/2	5 3/8	1 3/16	3 3/8	2 1/8	3	21 1/2	5 1/8
20	17	27	4 3/4	4 1/4	1 3/4	6	1 5/16	3 3/4	2 1/4	3 3/8	24 1/4	5 5/8
22	18 1/2	29 3/4	5 1/4	4 3/4	2 1/8	6 7/8	1 3/8	4	2 1/2	3 3/4	26 1/2	6 1/4
24	20	32 1/2	5 3/4	5 1/4	2 1/4	7 1/2	1 9/16	4 1/2	2 3/4	4 1/8	28 3/4	6 7/8
26	22	35	6 1/4	5 5/8	2 5/8	8 1/4	1 11/16	4 3/4	3	4 3/8	31 1/2	7 3/8
28	23 1/2	38	6 3/4	6	2 3/4	8 3/4	1 13/16	5 1/8	3 1/4	4 3/4	33 3/8	8
30	25	40 1/2	7 1/4	6 1/2	2 3/4	9 1/4	1 7/8	5 1/2	3 1/2	5 1/8	35 3/4	8 5/8
36	30	48 3/4	8 3/4	7 3/4	3 5/8	11 3/8	2 5/16	6 1/2	4 1/4	6 1/4	42 3/4	10 1/2

